



**Step #1**

Position the spa cover (in closed position) on the spa, making sure that all four corners are properly positioned and square on the spa.

**Step #2**

Using the #10 x 1-1/2" screws, attach the Left and Right Mounting Brackets to the appropriate sides of the spa. **Caution: to prevent splitting of wood cabinet, pre-drill holes with a 1/16" drill bit.**

**Step #3**

Connect the Pivot Arms to the Mounting Brackets (See Fig. 2). After the Pivot Arms are connected, tilt them back into the upright position.

**Step #4**

Insert the long end of the Support Arms into the Center Coupler piece. Then slide the Support Arms into the Pivot Arms (See Fig. 3).

**Step #5**

Lay the Covermate on the spa cover. Adjust the Center Coupler piece and Support Arms so that the Center Coupler is lying parallel to the spa cover's hinge about 1/2" away (See Fig. 4). Using the #10 self tapping screws, fasten the Support Arms to the Pivot Arms and the Center Coupler piece. **Note: Be sure to rotate the Center Coupler so that the inserted screws are at a horizontal angle with the heads facing the back of the spa.**

**Step #6**

Slip the black hand grips to the edge of the spa cover and snap the Small Black Dome Caps on the heads of all exposed #10 screw heads.

**Step #7**

Attach the provided 3 hook TowelMate on the preferred side of your Covermate by simply snapping it into place and inserting the middle self tapping screw (See Fig. 5).

**CAUTION!** Do not use the Covermate in high wind condition (greater than 10 m.p.h.). Injury from the spa cover being blown over and impacting the spa user can occur.

ITEM	PART#	DESCRIPTION	QTY
A	100001	SUPPORT ARM	2
B	100002	FOAM GRIP	2
C	100003	CENTER COUPLER	1
D	100004	PIVOT ARM	2
E	100007	PIVOT ARM CAP	2
F	100344	BUSHING	4
G	100561	MOUNTING BRACKET-LEFT	1
H	100562	MOUNTING BRACKET-RIGHT	1
I	100024	VINYL BLACK CAP	2
J	100008	TOWELMATE	1
K	100010	3/8 X 3" HEX CAP BOLT	2
L	100011	3/8 NYLON LOCKNUT	2
M	100012	3/8 FLAT WASHER	4
N	100013	#10 X 5/8" SELF TAPPING SCREWS	12
O	100909	#10 X 1-1/2" MOUNTING SCREWS	16
P	100015	LARGE BLACK DOME CAP	2
Q	100016	SMALL BLACK DOME CAP	30